

Assembly Instructions

Windsor 1180 Rocker

Rocker Tools Required

(Included)

- 1 Rocker Top
- 1 Rocker Base
- 6 Allen Head Screws
- 1 Allen Key

- 1. Lay rocker top, top side down on carpeting, towel or other soft cloth.
- 2. Place rocker base upside down on seat aligning holes in cross supports to the line
- 3. Lightly twist each screw through the back assemble holes into the seat bottom.
DO NOT TIGHTEN UNTIL ALL SCREWS HAVE BEEN "STARTED"
- 4. Tighten screws in holes.
- 5. Turn rocker over to the upright position